



Ø 41 mm

**1794 EF-316D-1AVEF**

Case: Stainless steel



Ø 41 mm

**1794 EF-316D-2AVEF**

Case: Stainless steel



Ø 39 mm

**1343 EF-304D-1AVEF**

Case: Stainless steel



Ø 42 mm

**2719 EF-126D-7AVEF**

Case: Stainless steel



Ø 40 mm

**2719 EF-125D-1AVEF**

Case: Stainless steel



Ø 40 mm

**2719 EF-125D-2AVEF**

Case: Stainless steel



Ionised bezel

Ø 45 mm

**5167 EF-131D-1A1VEF**

Case: Stainless steel



Ionised bezel

Ø 45 mm

**5167 EF-131D-7AVEF**

Case: Stainless steel



Ø 45 mm

**5125 EF-129D-1AVEF**

Case: Stainless steel



Ø 40 mm

**2719 EF-125D-7AVEF**

Case: Stainless steel



Ø 40 mm

**2719 EF-121D-1AVEF**

Case: Stainless steel



Ø 40 mm

**2719 EF-121D-2AVEF**

Case: Stainless steel



Ø 45 mm

**5125 EF-129D-2AVEF**

Case: Stainless steel



Ø 42 mm

**2719 EF-126D-1AVEF**

Case: Stainless steel



Ø 42 mm

**2719 EF-126D-2AVEF**

Case: Stainless steel



Ø 37 mm

**2719 EF-106D-2AVEF**

Case: Brass



Stopwatch 1/1,000 sec.

Ø 47 mm

**NEW****5202 EFA-133D-1AVEF**

Case: Stainless steel



Stopwatch 1/1,000 sec.

Ø 47 mm

**NEW****5202 EFA-133D-8AVEF**

Case: Stainless steel

